User Guide

Step 1: Turn on the book scanner.

Step 2: Open the "CZUR Scanner application" on the desktop.

Step 3: Place the documents and books you want to scan within the black area.

① Scanner's switch   ② CZUR Scanner application

③

Processing method	Flat Single Page	Facing Pages	Combine Sides	Manual Selection
○ [Flat Single Page] ○ [Facing Pages] ○ Combine Sides ○ Manual Selection ○ No Processing	**Flat Single Page**	**Facing Pages** Scan with or without using the paperweight.	**Combine Sides** Combine two scans into a single A4 or A3 file.	**Manual Selection** Select the area you want to scan.

Step 4: Click the "Scan" button to enter the scanning interface.

Step 5: Select the "Color mode" and the processing method.

Step 6: Click "Auto Scan" button to start the scanning.

Step 7: Click the "Back" button to adjust the images using tools and "Export" them to your hard disk.

⑦ Back

⑦ Export

Color mode
○ Auto Enhance
○ Color
○ B&W
○ Grayscale
○ Stamps
○ Patterns
○ Non-filter

⑤ Color mode

Tools   ④ Scan

⑥ Auto Scan